

Other precautions

Syntax

Item	Description
Case sensitivity	The robot programming language is case-sensitive. <i>a</i> and <i>A</i> are distinguishable from each other.
Separator	Program elements in the robot programming language can be separated with commas (",") or spaces. For example, " <i>a1=0 a2=1 a3=2</i> " is equivalent to " <i>a1, a2, a3 = 0, 1, 2</i> ".
When variable count is greater than value count	<i>nil</i> is assigned to the empty variable. For example, in the statement of " <i>a1, a2, a3 = 0, 1</i> ", the value of <i>a3</i> is <i>nil</i> .
When variable count is smaller than value count	The redundant value is ignored. For example, in the statement of " <i>a1, a2 = 0, 1, 2</i> ", the value 2 is ignored.

Variable declaration

In the robot programming language, if you do not use the "local" keyword before the variable declaration, the variable is a global variable. See the following example.

<i>a=1</i>	-- Set <i>a</i> as a global variable
<i>if a == 1 then</i>	
<i>local b = 2</i>	-- Set <i>b</i> as a local variable
<i>end</i>	
<i>if b == 2 then</i>	-- The value of <i>b</i> is <i>nil</i> here, so this statement is not executed.
<i>c = 1</i>	
<i>end</i>	

Reserved keywords

The keywords in Delta's robot programming language is case-sensitive. For instance, *and* is distinguishable from *AND*.

Pay special attention when naming the variables. The following keywords cannot be used to declare the variable names.

<i>and</i>	<i>global</i>	<i>or</i>	<i>until</i>
<i>boolean</i>	<i>goto</i>	<i>P</i>	<i>while</i>
<i>break</i>	<i>if</i>	<i>p</i>	All the instruction names
<i>do</i>	<i>in</i>	<i>repeat</i>	
<i>else</i>	<i>local</i>	<i>return</i>	
<i>elseif</i>	<i>nil</i>	<i>string</i>	
<i>end</i>	<i>not</i>	<i>table</i>	
<i>false</i>	<i>number</i>	<i>then</i>	
<i>for</i>	<i>OFF</i>	<i>thread</i>	
<i>function</i>	<i>ON</i>	<i>true</i>	