

2.3.2 World frame mode

The World frame mode is the base coordinate frame of reference, which is preset by the system and cannot be changed. After you select **World** for the Mode, the User Frame ID and Tool Frame ID are automatically set to 0 and cannot be modified.

Mode

Mode :

World

User Frame ID :

0

Tool Frame ID :

0

