

2.5.3 Operator area

The Operator area is at the bottom of the **JOG** subpage for the operating personnel to operate the robot and check for the coordinates of the robot axes at present.

When you select **World**, **User**, or **Tool** for the Mode, the Operator area shows the Cartesian coordinates.

See the following figures.

When a SCARA robot is connected, you can control the movements of the X, Y, Z, and RZ axes in the Operator area.

When a VA robot is connected, you can control the movements of the X, Y, Z, RX, RY, and RZ axes in the Operator area.

Operator area for SCARA	Operator area for VA
Operator X: 275.617 mm Y: -141.767 mm Z: -8.208 mm RZ: 0.000 deg	Operator X: 444.000 mm Y: 0.000 mm Z: 754.000 mm RX: 0.000 deg RY: -90.000 deg RZ: -180.000 deg