

■ Point operation areas

You can use the Motion Command area to send commands to the robot. The Point operation areas of the **Local** and **Global** tabs are shown and detailed as follows.

Local Point

Add

Clear

Delete

Save

Motion Command(mm)

Please choose one point

File: Global

Teach

☐ Check All

Maximum Top

Name:

Ext Teach

Rise height

Motion: MovP

Go

Drop height

Point operation areas of the **Local** tab

Global Point

Refresh

Clear

Motion Command(mm)

Please choose one point

File: Global

Teach

☐ Check All

Maximum Top

Name: GL_1

Ext Teach

Rise height

Motion: MovP

Go

Drop height

Point operation areas of the **Global** tab

Area	Name	Description
Local Point	Add	Add a local point. Up to 6,000 points can be saved in one project.
	Delete	Select the check box(es) in the Check column, and then click this button to delete the local point(s). After deletion, the IDs of the following points are shifted up.
	Clear	Select the check box(es) in the Check column, and then click this button to clear the data of the point(s).
	Save	Save the point data.
Global Point	Refresh	Refresh the data in the Global tab.
	Clear	Select the check box(es) in the Check column, and then click this button to clear the data of the point(s).
Motion Command (mm)	Teach	Use the JOG subpage functions to move the robot to the target position. Select one global or local point, and then click Teach to save the current position of the robot to the point file.
	Ext Teach	Teach the external axis.
	Check All	Select all the check boxes in the Check column.
		A drop-down list box that displays the name of the external axis if one is connected.
	Go	Select one point and then press and hold this button to move the robot to the point. Release the button to stop the robot.
	File	Displays "Local" for Local tab. Displays "Global" for Global tab.
	Name	Displays the name of the currently selected point.