



Area	Name	Description
Motion Command (mm)	Motion	■ MArchP The robot moves from the current position to the target point with linear motion, arc motion, and joint motion. You need to first set the maximum ascending height (Maximum Top), ascending height (Rise height), and descending depth (Drop height) for the Z axis. Maximum Top -10 Rise height 30 Drop height 50  (A) Maximum Top; (B) Rise height; (C) Drop height; (P1) Current position; (P2) Target point ■ MArchL The robot moves from the current position to the target point with linear motion and arc motion. You need to first set the maximum ascending height (Maximum Top), ascending height (Rise height), and descending depth (Drop height) for the Z axis. Maximum Top -10 Rise height 30 Drop height 50  (A) Maximum Top; (B) Rise height; (C) Drop height; (P1) Current position; (P2) Target point Important: when performing arc motions, make sure the current height of Z axis does not exceed the Maximum Top setting.