


■ Subpage

Go to the **JOG** subpage to control the jogging of the robot. Refer to the descriptions as follows.



Area	Name	Description
Setting	Mode	Select the coordinate frame (Mode) among Joint , World , User , and Tool .
	UF	Set the User Frame ID (ranges 1 to 9). The default setting is 0, indicating the User Frame directions are the same as that of the World frame.
	TF	Set the Tool Frame ID (ranges 1 to 9); the default setting is 0.
	Distance	Set the robot to move continuously or discontinuously. Refer to Section 2.5.1 Setting area for details.
Posture		Shows the postures of the robot at present and the JRC count of the end of the robotic arm. Refer to Section 2.5.2 Posture area, and Section 4.3.1 JRC (Joint Rotation Count) for details.
Operator		Shows the axis positions of the robot at present and the operation buttons for controlling the axis moving directions. Refer to Section 2.5.3 Operator area for details.