

4.2 Point teaching

This section introduces the methods and the related pages of point teaching.

4.2.1 Function areas for point teaching

Go to the **Point** subpage.

Point

Offset

Select points before setting offset

Offset

ΔX (mm):

0.0

ΔY (mm):

0.0

ΔZ (mm):

0.0

ΔRZ (deg.):

0.0

Lift Motion

Orientation (degree):

90.000

Deg. (degree):

0.000

Height (mm):

0.000

File Operate

Import

Export

JRC Operate

1 : JRC Active

Active

Area	Description
Offset	Perform offsetting for the selected point. You need to first select the point to be offset by selecting the check box in the Check column in the Point management page.
Lift Motion	Parameter settings for the Lift motion.
File Operate	Import a point file to the current project, or export the point data of the current project. The supported file format is CSV. The order of columns in the CSV file must align with that in the Point management page.
JRC Operate	Refer to Section 4.3.2 JRC_Active (axis rotation mode) for details.