

4.3 Point data

This section introduces the columns in the **Local** / **Global** tab of the Point management page for SCARA and VA robots, which are shown as follows.

Local												
	Check	Name	X (mm)	Y (mm)	Z (mm)	RZ (degree)	Hand	UserID	ToolID	CoordinateStr	J4_JRC	JRC_Active
▶ 1001	☒	p1001	0.000	0.000	0.000	0.000	0	0	0	User	0	4

Local tab for SCARA robots

Local												
	Check	Name	X (mm)	Y (mm)	Z (mm)	RX (degree)	RY (degree)	RZ (degree)	Elbow	Shoulder	Flip	JRC_Active
▶ 1001	☒	p1001	10.000	20.000	30.000	-20.000	10.000	30.000	0	0	0	1

Local tab for VA robots

Column	Description
Check	Select the row(s) of point you want to delete or clear.
Name* ¹	Name of the point. Click in the field to change the name; otherwise, the default name is displayed.
X (mm)	The X axis position in the corresponding coordinate frame.
Y (mm)	The Y axis position in the corresponding coordinate frame.
Z (mm)	The Z axis position in the corresponding coordinate frame.
RX (degree)* ²	The RX axis angle in the corresponding coordinate frame.
RY (degree)* ³	The RY axis angle in the corresponding coordinate frame.
RZ (degree)	The RZ axis angle in the corresponding coordinate frame.
Elbow* ²	Elbow condition of the robot. 0: elbow down; 1: elbow up.
Shoulder* ²	Shoulder condition of the robot. 0: shoulder back; 1: shoulder front.
Flip* ²	Wrist condition of the robot. 0: no-flip; 1: flip.
Hand* ⁴	Arm configuration of the robot. 0: right-handed; 1: left-handed.
UserID	User Frame ID.
ToolID	Tool Frame ID.
CoordinateStr	Coordinate frame (Mode).
J4_JRC	The JRC (Joint Rotation Count) of the J4 axis.
J6_JRC	The JRC (Joint Rotation Count) of the J6 axis.
JRC_Active	The rotation mode of the axis during robot operation.

Note:

- Local points: only English letters and numbers can be used for naming the point.
Global points: the name of the point must start with "GL_" and be followed by an English letter or a number, such as GL_1 or GL_A. If the system cannot identify the name you input, the default name is automatically applied.
- Only applicable to VA robots.
- Only applicable to VA robots and 5-axis SCARA robots.
- Only applicable to SCARA robots.