

4.3.2 JRC_Active (axis rotation mode)

The JRC_Active sets the way the rotation axis moves during robot operation. Switch to different rotation modes by setting the JRC_Active to 1 - 4 (0: disable the axis rotation mode). You can also set the mode in the JRC Operate area of the **Point** subpage.

The JRC_Active column in the **Local** / **Global** tab of the Point management page:

Local													
	Check	Name	X (mm)	Y (mm)	Z (mm)	RZ (degree)	Hand	UserID	ToolID	Coordinate	CoordinateStr	J4_JRC	JRC_Active
1001	☐	p1001	400.000	0.000	0.000	194.711	0	0	0	1	User	1	4
1002	☐	p1002	400.000	0.000	0.000	360.000	0	0	0	1	User	2	4
1003	☐	p1003	400.000	0.000	0.000	-180.762	0	0	0	1	User	1	4
1004	☐	p1005	0.000	0.000	0.000	0.000	0	0	0	1	User	0	4

The JRC Operate area of the **Point** subpage:

Point

Offset

Select points before setting offset

Offset

ΔX (mm):

0.0

ΔY (mm):

0.0

ΔZ (mm):

0.0

ΔRZ (deg.):

0.0

Lift Motion

Orientation (degree):

90.000

Deg. (degree):

0.000

Height (mm):

0.000

File Operate

Import

Export

JRC Operate

0 : JRC Inactive

Active