

- **Status of Source/ Ambient Temperature and Fan Speed:**

Status	Source Temperature	Ambient Temperature	Fan speed (Duty cycle %)
1	X ^{*7}	< 50°C	Stop (0%)
2	< 25°C	X ^{*7}	Stop (0%)
3	< 20°C	< 20°C	Min (20%)
4	< 25°C	< 20°C	Min (20%)
5	< 25°C	> 25°C	Max (100%)
6	< 25°C	> 50°C	Stop (0%)
7	> 25°C	< 20°C	Stop (0%)
8	> 25°C	> 25°C	Stop (0%)
9	> 25°C	> 50°C	Stop (0%)

- **Fan running conditions:**

1. Both temperature cables must be correctly connected to relevant ports. If either of the two temperature cables is not well connected or is not connected to the right port, the fans won't run.
2. The source temperature must be lower than the ambient one; otherwise, the fans won't run or will stop running.
3. The source temperature determines whether the fans run or not.
4. The ambient temperature determines fan speed.



NOTE: When the fans won't run or stop running, please check if the two temperature cables are correctly connected and work normally, or follow this User Manual to adjust source and ambient temperatures. If the causes above are eliminated but the fans still don't run, contact your local dealer or customer service.

~~~~~  
 \*7: X means that the ADU can't detect the source or ambient temperature. Possible causes might include the temperature cable is not well connected or is not connected to the right port or has failed.