



Chapter 5: Maintenance

Higher temperatures shorten fan life. Please periodically check if the fan(s) works normally and ensure that cool air flows freely through the ADU. Regular maintenance at least once every half year or periodic maintenance when cool air supply volume decreases is highly recommended.

Do not take apart the ADU; only qualified personnel can do so. If you wish to clean the ADU, you can clean the exterior by observing the following procedure. If you wish to clean the inside, please contact your local dealer or customer service.

- **Cleaning the ADU's Exterior:**

1. Lift the raised floor under which the ADU is installed.
2. Turn off the ADU, check whether the system status LED indicator is off, and wait until all fans stop running.
3. Remove the power cord and two temperature cables.
4. Loosen the 4 screws attached to the raised floor to separate the ADU from the raised floor.
5. Use a soft brush to gently clean the exterior of the ADU.
6. After cleaning, please refer to **Chapter 3** to reinstall the ADU.
7. Run the ADU for a while and observe if there is any abnormal vibration or noise. If yes, please contact your local dealer or customer service.



WARNING:

Please ask your local dealer or customer service for more maintenance information. Do not perform maintenance if you are not trained for it.