



Chapter 6: Troubleshooting

When an alarm goes off, please follow the solutions shown below.

No.	Signal	Alarm	Troubleshooting
1.	System Fail	Output over voltage	1. Check system-status LED indicator. 2. If the LED flashes (green), it indicates that the ADU has abnormal output voltage ^{*13}. 3. If the LED is off, it indicates that the ADU has over current or shorting issues ^{*13}.
2.	Temp. Fail	1. Source temperature > 20°C ^{*11} 2. Ambient temperature > 25°C (or 27°C) ^{*12}	1. Inspect the source temperature. If it is higher than 20°C, check whether the air cooling system turns on and runs normally. If yes, decrease the air cooling system's temperature. 2. Check the ambient temperature. If it is higher than 25°C (or 27°C) ^{*12}, turn off some of the equipment in the cabinet/ enclosure to decrease the ambient temperature. 3. If source and ambient temperatures are both within the normal ranges and two temperature cables are correctly connected but the alarm remains on, replace temperature cables to test whether the cables are abnormal. 4. If the results prove that two temperature cables are normal and the alarm still exists, it indicates that an internal fault has occurred ^{*13}.