

3.	Fan Fail	Fan missing/failure	1. Check if all fans (6 PCS) are installed inside the ADU. If any are missing, please contact the dealer. 2. If cool air can still flow out of the ADU, inspect if any foreign matter is stuck in a fan. If not, it indicates that the non-running fan(s) has failed ^{*13}. 3. If no cool air comes out of the ADU, inspect: 1) Whether the two temperature cables are correctly connected. 2) Whether the source or ambient temperature is affecting the fan running condition. 3) If all of the above root causes are eliminated and the alarm remains on, it indicates that an internal fault has occurred ^{*13}.
4.	High-Temp. Alarm	Environment over temperature (Ambient temperature > 50°C)	1. Check if the ambient temperature is higher than 50°C. If yes, turn off some of the equipment in the cabinet/ enclosure to decrease the ambient temperature. 2. If the ambient temperature is normal and the ambient temperature cable is correctly connected but the alarm still exists, replace the temperature cable to test whether the cable is abnormal. 3. If the test result proves that the temperature cable is normal and the alarm is still on, it indicates that an internal fault has occurred ^{*13}.

^{*11}: The operating temperature is 10°C~20°C.

^{*12}: The operating temperature is 20°C~25°C (or 27°C) according to the setup of DIP 1 switch (please see **Chapter 4 'DIP Switch'** for detailed information).

^{*13}: When abnormal output voltage, over current, shorting issues, fan missing/ failure, or an internal fault occurs, please contact your local dealer or customer service.