

**NOTE:**

If you have previously changed the Mini SNMP's Host Name or IP Address, connect with the new settings.

- Step 2** Log in as Administrator (default account/ password: admin/ password, case sensitive).
- Step 3** Specify your preferred display language (default: English) from the drop-down menu on the top right of the page. The Mini SNMP will remember your language preference. In the following instructions, English is chosen as the display language.
- Step 4** Click **System** → **User** → **Local**. Manage your login accounts and passwords under the “User” subhead. The access permission for the account types is shown as follows:
- 1) **Administrator:** Allowed to modify all settings.
 - 2) **Device Manager:** Allowed to modify device-related settings.
 - 3) **Read Only User:** Only allowed to view settings without the permission to make changes.

You can manually specify whether users are allowed to log in from other LANs. If you wish to block login attempts from external connections, select **Only in This LAN**. Otherwise, select **Allow Any**.

- Step 5** Click **System** → **Ethernet** to set Host Name, IP Address, Subnet Mask and Gateway IP for the Mini SNMP.
- Step 6** Click **System** → **Service** → **Time** to manually set time and date for the system, or enable automatic time synchronization between the Mini SNMP and the time servers.

**NOTE:**

To completely set up your Mini SNMP, please refer to **Chapter 5: InsightPower G3 Mini SNMP Web**.