

4-3 Configuring via Telnet

- Step 1** Plug a CAT5 cable into the Mini SNMP's network port.
- Step 2** Connect the workstation (Windows or Linux) to the LAN that the Mini SNMP is connected to.
- Step 3** For Windows, launch DOS prompt mode (**Start** → **Run** → key in **cmd** and press **Enter**). For Linux, launch Shell.
- Step 4** Enter the following command: **telnet Host Name** or **telnet IP address** to initiate telnet connection with the Mini SNMP.
- Step 5** When connection is established, enter Administrator's account and password (default: admin/ password, case sensitive). The Main Menu will appear on the screen. Please refer to **4-5 Configuring via Text Mode** for more information.

**NOTE:**

1. The Mini SNMP terminates idle connections after 60 seconds.
2. Refer to **Chapter 5: InsightPower G3 Mini SNMP Web** for the complete configuration procedures.

4-4 Configuring through COM Port

If network connection is not available at your location, you can still set up the Mini SNMP via COM port. Please follow the instructions below.

**NOTE:**

If you are running a non-Windows system, refer to your system's user manual for Telnet clients.

- Step 1** Use the provided RJ45 to DB9 cable to connect the Mini SNMP's COM port to the workstation's COM port.
- Step 2** Download the free Telnet/ SSH client program named PuTTY from <http://www.putty.org>.