



**Step 6** Click **Open** to continue, and PuTTY will automatically connect to the Mini SNMP. When connection is established, log in with Administrator's account/ password (default: admin/ password, case sensitive). Once you are logged in, the Main Menu appears on the screen. Please refer to **4-5 Configuring via Text Mode** for more information.

## 4-5 Configuring via Text Mode

You can configure the Mini SNMP via text mode by using Telnet/ SSH clients such as HyperTerminal and PuTTY. Refer to the default settings and details below.

### ● Main Menu

