

● User Manager

```

=====
|   User Manager   |
=====
Local Auth
Administrator
[1]. Account:      admin
[2]. Password:     *****
[3]. Limitation:   LAN
Device Manager
[4]. Account:      device
[5]. Password:     *****
[6]. Limitation:   LAN
Read Only User
[7]. Account:      user
[8]. Password:     *****
[9]. Limitation:   ANY
[0]. Back To Previous Menu
Mini>

```

No.	Item	Description	Default
[1]	Administrator Account	The default account/ password for the Administrator (case sensitive).	admin
[2]	Administrator Password		password
[3]	Administrator Limitation	Limitation on Administrator login area.	LAN
[4]	Device Manager Account	The default account/ password (case sensitive) for the Device Manager. This account is only permitted to change device-related settings.	device
[5]	Device Manager Password		password
[6]	Device Manager Limitation	Limitation on Device Manager login area.	LAN
[7]	Read Only User Account	The default account/ password (case sensitive) for Read Only User. This account is only allowed to view settings without the permission to make changes.	user
[8]	Read Only User Password		password
[9]	Read Only User Limitation	Limitation on Read Only User login area.	Any