

 **Soft Restart**

Reset the Mini SNMP. This will not affect the operation of the UPS.

 **Reset All to Default**

Reset to manufacturer default.

 **Exit Without Save**

Exit without saving your setting changes.

 **Save and Exit**

Save your setting changes before you exit.