



5-2 Device

5-2-1 Management

Since different UPSs have different functions, your UPS may not support the same configuration or control items stated below.

Configure

Go to **Device** → **Management** → **Configure** to configure the UPS. The configuration values are saved in the UPS or in the Mini SNMP, and these values change UPS operation. The configuration items include the following. Please note that different UPSs may support different configuration options.



- **Auto Restart**

After you click **Submit** to confirm your auto restart setup, the Mini SNMP will send the command to the UPS to enable auto restart.

- **UPS Buzzer**

After you click **Submit** to confirm your buzzer setup, the Mini SNMP will send the command to the UPS to enable the buzzer.