

## Control

Go to **Device** → **Management** → **Control** to configure relevant control commands. After you click **Submit**, the Mini SNMP will send the commands to the UPS to enable relevant functions. The control items include the following.



- **Battery Test**

After you select the battery test type and click **Submit**, the Mini SNMP will send the command to the UPS to enable the battery test accordingly.

- **Shutdown & Restart UPS Only**

After you confirm your setup, the Mini SNMP will send the command to the UPS to shut down or/ and restart the UPS.

If you want to shut down the UPS, please check the UPS Shutdown Delay box and key in the delay time.

If you want to restart the UPS, please check the UPS Restart Delay box and key in the delay time.

If you want to shut down and restart the UPS, please check both of the boxes and key in the delay time for both.

- **Smart Shutdown**

Via the Smart Shutdown configuration, you can safely shut down all of the connected computers and the UPS. First of all, you should estimate the longest OS Shutdown Delay time of your operating systems, which have the shutdown software installed and are connected to the Mini SNMP. The Mini SNMP will wait for all the operating systems to shut down according to the OS Shutdown Delay time, and then it will send the UPS Shutdown Delay time to the UPS for a safe shutdown.