



- **FTP**  
Enable/ Disable FTP connection.
- **FTP Port**  
Assign a FTP port number (default: 21).
- **SFTP**  
Enable/ Disable SFTP connection.
- **SSH Port**  
Assign a SSH port number (default: 22).

### ● Time

You can manually set the time and date or allow automatic time synchronization with the SNTP server. Please note that if the SNTP server is not responsive, the event and data logs will not be registered even when SNTP is enabled.

