

- **Simple Network Time Server**

- 1) **Time Zone:** From the dropdown menu, select the time zone according to the location of the Mini SNMP.
- 2) **Primary/ Secondary Time Server:** Two time servers can be added. Every Period Time, the Mini SNMP synchronizes with the first responding server.
- 3) **Synchronization Period:** The time interval that the Mini SNMP synchronizes with the SNTP server.
- 4) **Update time to UPS:** Determine whether to synchronize the time with the UPS.
- 5) **Enable Daylight Saving:** Check to enable daylight saving time. During this period, the time of Mini SNMP advances by one hour.

- **Manual**

If a time server is not accessible, you can still manually set the time and date. Please note that every time you restart the Mini SNMP's network module, the time and date will be reinstated to the time you've set.

## **SNMP**

The Mini SNMP supports SNMP protocol, which is commonly used to monitor network devices and send notifications when there is any abnormality. To prevent unauthorized access, you can specify the allowed NMS IP addresses and set up their community strings and access levels. The maximum number of the IP entries is 16.



### **NOTE :**

If the IP address \* is enlisted, the NMS IP access restriction will be ignored. The Mini SNMP checks the community string to identify the access level and permission according to your setting.