

Configuration

System Identification

*Host Name(NetBIOS):

System Contactor:

System Location:

Date/Time

☐ NTP ☒ Manual

Time Zone: GMT Dublin, Lisbon, London

*1st Time Server Name or IP: POOL.NTP.ORG

2nd Time Server Name or IP:

Set Current Time: Date 08/04/2017 (MM/DD/YYYY)

Time 13:13:07 (hh:mm:ss)

User Limitation

Administrator: ☐ In The LAN ☒ Allow Any

Device Manager: ☐ In The LAN ☒ Allow Any

Read Only User: ☐ In The LAN ☒ Allow Any

Reset to Default SNMPv3... OK Cancel

IPv4

BOOTP/DHCP Client: ☒ Enable ☐ Disable

*IP Address: 192 . 168 . 1 . 100

*Subnet Mask: 255 . 255 . 255 . 0

Gateway IP: 192 . 168 . 1 . 254

DNS IP: 0 . 0 . 0 . 0

IPv6

DHCPv6 Client: ☐ Enable ☒ Disable

*IP Address: ::

*Prefix Length: 0

Gateway IP: ::

DNS IP: ::

System Configuration

HTTP Server: ☒ Enable ☐ Disable

Telnet Server: ☒ Enable ☐ Disable

HTTP Server Port: 80

Telnet Server Port: 23

* Fields marked with an asterisk indicate recommended settings and inputs.

Q4. Unable to connect to the Mini SNMP via its Host Name.

If you just assign a new static IP address to the Mini SNMP, you may need to refresh the NetBIOS table so that it corresponds with the new setting. Although Windows updates its NetBIOS table periodically, you can still manually force it to refresh by entering the following command **nbtstat -R** in DOS prompt mode. After that, you can connect to the Mini SNMP by its Host Name. Please also ensure that the Host Name assigned to the Mini SNMP does not exceed 16 bytes.

Q5. How to check my workstation's IP address?

For Windows, please enter **ipconfig /all** in DOS prompt mode. For UNIX, please enter **ifconfig** in shell. You should be able to check your IP and MAC (Physical Address) now.

```
Physical Address. . . . . : 00-23-4D-A2-3A-2C
DHCP Enabled. . . . . : Yes
Autoconfiguration Enabled . . . . : Yes
Link-local IPv6 Address . . . . : fe80::ad55:5b9b:74c6:e5fc%12(Preferred)
IPv4 Address. . . . . : 172.16.186.97(Preferred)
Subnet Mask . . . . . : 255.255.254.0
```

```
C:\>
```