

Q6. Unable to ping the Mini SNMP from my workstation.

If the Mini SNMP is non-responsive, check the following:

- 1) If the green LED indicator on the Mini SNMP is OFF, check if the network cable is connected correctly from the Mini SNMP to the router or hub.
- 2) If the green LED indicator is ON, the problem may be a pinging failure due to incorrect IP address. Manually assign a valid IP address to the Mini SNMP.
- 3) If the green LED indicator flashes and (1) your network configuration includes a DHCP server, make sure the DHCP service is working properly. (2) Otherwise, make sure the assigned IP is not taken on the network. Please note that if the current configuration is not useable, the Mini SNMP will use the default IP settings (IPv4 address: 192.168.1.100/ net mask: 255.255.255.0/ gateway: 192.168.1.254).
- 4) If the problem persists, use a network cable to connect the Mini SNMP and the workstation. Ping the Mini SNMP's default or static IP address depending on your configurations. If it pings successfully, it means that the Mini SNMP is normal. Check your network equipment. Otherwise, contact your local dealer or service personnel for assistance.

Q7. Unable to perform an SNMP Get command.

Refer to **5-3-2 Service** to check the SNMP settings. Make sure that the workstation's IP address is added to the NMS IP list with Read Only or Read/ Write permission. The community string on the workstation and the Mini SNMP must match.

Q8. Unable to perform an SNMP Set command.

Refer to **5-3-2 Service** to check the SNMP settings. Make sure that the workstation's IP address is added to the NMS IP list with Read/ Write permission. The community string on the PC and the Mini SNMP must match.

Q9. Unable to receive SNMP trap.

Refer to **5-3-3 Notification** to check the SNMP Trap settings. Make sure that the workstation's IP address is added to the Target IP list.