

Chapter 3 : Operation Modes

The APF is applicable to many applications and can meet the particular installation requirements of industrial sites, power distribution rooms and IT data centers. According to different work conditions and environment requirements, APF modules can be installed in a standard or customized cabinet. Flexible configurations and on-site capacity expansion can also be achieved based on current and subsequent capacity requirements.

3.1 Pre-installation Confirmation

Since the installation environment varies for different users, please be sure to read this Manual carefully before installation. All installation, assembly and start-up work must be carried out by the qualified professional personnel. If the work is to be carried out by the customer, it shall be under the supervision of the qualified professional personnel. When a forklift or similar lifting equipment is used to handle the device, make sure the lifting capacity is sufficient. Please refer to **Table 2-10** for the APF weight,

3.2 Installation Environment

1. APF system must be installed indoors. Outdoor installation is strictly prohibited. Please take into full consideration the equipment's standard IP30 or IP54 protection rating.
2. APF equipment should not be placed in a sandy/dusty area or a heavily polluted environment. If installation in such environment is required, please confirm what precaution measures shall be taken with Delta or Delta's distributor. Electrically conductive dust particles can damage the equipment. Please make sure that there are no such particles present inside the installation area.
3. Please make sure that the passageways and the placement location are large enough to accommodate the forklift and system cabinet, and verify that the installation location is capable of withstanding the weight.
4. While the APF is operating, it makes sound at a certain noise level. Please take the noise into consideration when deciding where to install and place the unit.
5. The installation location must be kept clean and tidy. Please make sure that the input wires are properly sealed to prevent rats from rodent damage.
6. Please make sure that the installation area is spacious enough for conducting maintenance work. While installing the APF, we suggest that the ventilation inlet openings shall be at the front and that the ventilation outlet openings shall be at the back. Maintain a clearance of 1,000 mm at the front and back of the APF cabinet for operation, maintenance, and wiring. When installation against the wall is required, top-airflow type cabinet shall be selected. Please consult Delta or Delta's distributor for cabinet's airflow type. Corresponding ventilation fans shall be installed to satisfy the APF ventilation requirement.