

Chapter 6 : Maintenance

- **SVG**

1. SVG Cleaning:

Regularly clean the SVG, especially the slits, openings and filters, to ensure that the air freely flows into the SVG to avoid overheating. If necessary, use an air blower or vacuum cleaner to clean the slits and openings and replace the filters regularly to prevent any object from blocking or covering these areas.

2. SVG Regular Inspection:

Please contact Delta or Delta distributor for the maintenance service.

- **Fans**

Higher temperature will shorten the life span of the fan. When the SVG is running, please check if all fans work normally and make sure if air can move freely around and through the SVG. If not, please replace the fan.



NOTE:

Please Contact Delta or Delta distributor for more maintenance information. Do not perform maintenance if you are not trained for it.