

READ PRIOR TO INSTALLATION FOR SAFETY.

 DANGER	☑ Disconnect AC input power before connecting any wiring to the motor. ☑ Never modify the internal components or wiring. ☑ Ground the motor by using the ground terminal. The grounding method must comply with the laws of the country where the motor is to be installed. ☑ Do NOT install the motor in a location with high temperature, direct sunlight or inflammable materials or gases.
 CAUTION	☑ Never connect the motor output terminals U/T1, V/T2 and W/T3 directly to the AC mains circuit power supply. ☑ After finishing the wiring of the motor, check if U/T1, V/T2, and W/T3 are short-circuited to ground with a multimeter. Do NOT power the drive if short circuits occur. Eliminate the short circuits before the motor is powered. ☑ Only qualified persons are allowed to install, wire and maintain the motor. ☑ Pay attention to the following precautions when transporting and installing this package (including wooden crate and wood stave) 1. If you need to deworm the wooden crate, do NOT use fumigation or you will damage the drive. Any damage to the motor caused by using fumigation voids the warranty. 2. Use other methods, such as heat treatment or any other non-fumigation treatment, to deworm the wood packaging material. 3. If you use heat treatment to deworm, leave the packaging materials in an environment of over 56°C for a minimum of thirty minutes. ☑ This motor must be kept away from high temperature, moisture, dripping water, corrosive substances, dust in the air and electric shock or vibration

NOTE:

1. In the figures in this manual, the cover or safety shield is disassembled only when explaining the details of the product. During operation, install the top cover and wiring correctly according to the provisions. Refer to the operation descriptions in the manual to ensure safety.
2. The figures in this instruction are only for reference and may be slightly different depending on your model, but it will not affect your customer rights.
3. The content of this manual may be revised without prior notice. Consult our distributors or download the latest version at http://www.deltaww.com/iadownload_acmotordrive