

NOTE:

1. The following description takes foot-pads installation (IM B3) as the example.
2. Consult with Delta for Non-B3 installation.
3. If the applied force exceeds this limit, consult with Delta.
4. Standard bearing model: applied to direct connection and coupling installation application (if using a belt, follow Delta's radial force specifications).

Precautions for belt drive:

1. For all belt/ chain/ gear applications, the force on the D end must NOT exceed the value recommended by Delta to avoid damage to the motor bearing. If the application exceeds this limit, consult with Delta.
2. When installing the belt, follow the manufacturer's recommended value for belt tension, center distance, number of strands and model to avoid belt slippage and burning or replacement ahead of normal lifespan due to belt over-tightening.
3. As mentioned above, the motor mounting base needs a slide rail adjustment mechanism to adjust the tension by adjusting the bolts (or screws); an idler wheel design can adjust the tension by moving the idler wheel horizontally.
4. The belt tension will loosen over time, it is necessary to regularly check whether the tension value is too low.
5. When installing the pulley, it should be as close to the motor as possible to reduce bending stress. The center points of the driving end and the driven end of the pulley should be aligned. Pay extra attention to the parallelism of the rotation axis to avoid belt breakage due to skewness or torsion.
6. There should be no belt jumping, friction, slipping, abnormal noise or abnormal vibration during operation.
7. Use a tapered sleeve pulley connection to fasten the pulley, in order to cope with different working conditions of the client and to prevent axial displacement of the pulley, key and shaft, also avoid stress concentration that may cause the motor slip or failing to transmit power.

Correct Belt Installation (OK)	Incorrect Belt Installation (NG)	
	Example 1	Example 2
		