

Software Introduction

1

This chapter provides information about the use and overview of DRASstudio.

1.1	Required environment	1-2
1.2	Screen overview	1-3
1.3	Quick access toolbar	1-4
1.3.1	Login permissions	1-5
1.3.2	Robot model selection	1-7
1.3.3	Connection	1-9
1.3.4	Servo control	1-10
1.3.5	TP status	1-10
1.3.6	Operation mode	1-11
1.3.7	Alarm	1-13
1.3.8	Reset (alarm reset)	1-13
1.3.9	Manual	1-14
1.3.10	Speed Override	1-14
1.3.11	Switch for Subpage	1-14
1.4	Main page	1-15
1.5	Subpage	1-17
1.5.1	Output	1-18
1.5.2	Alarm	1-18
1.5.3	Project	1-19
1.5.4	Point	1-19
1.5.5	WorkSpace	1-20
1.5.6	JOG	1-20
1.5.7	Function	1-21
1.5.8	Status	1-22
1.5.9	ExternalAxis	1-22
1.5.10	RL	1-23
1.5.11	IO	1-24