

10. Click **Back** to return to the **Tool Frame** tab.

4

Tool size calculation

Tool Frame

ID : 5

Input : Enter data of each axis and Height by teach, and then calculate.

X (mm)	Y (mm)	Z (mm)	Error	Select
423.318	244.237	-66.658	1.353	☒
528.176	119.872	-72.487	1.873	☒
376.553	27.968	-73.97	1.242	☒
0	0	0	0	☐
0	0	0	0	☐
0	0	0	0	☐
0	0	0	0	☐
0	0	0	0	☐

Output :

Height (mm): 123.405

Width (mm): -117.149

Angle (degree): 6.403

Buttons: Back, Save, Teach, Clear, Calculate, Set

11. Select the Tool Frame ID for which you just set the too size, and then the set size is displayed in the Tool Size area.

Tool Frame

ID : 5

Tool Size

Input :

(1) Enter the tool size

Width (mm)	Height (mm)	Angle (degree)
123.405	6.403	-117.149

(2) Determine the tool size by teaching

Determine

Buttons: Tool Size Set, Get