

4

Method for teaching the Tool Frame directions

If you want to calculate the Tool Frame directions by teaching, click **Determine** in the Tool Orientation area.

Note: you can define the Yaw for the 4-axis SCARA robots; Pitch and Yaw for the 5-axis SCARA robots; Roll, Pitch, and Yaw for the VA robots.

Tool Orientation

Input :

(1) Enter the tool orientation data (Unit : Degree)

Roll (RX)	Pitch (RY)	Yaw (RZ)
0.000	0.000	0.000

(2) Determine the tool orientation data by teaching

Determine

Tool Orientation Set

The system then displays the Tool Orientation Calculation screen:

Tool Frame

Tool Orientation Calculation

ID : 1

Input :

Enter data and Calculate

	X (mm)	Y (mm)	Z (mm)
Origin	0	0	0
+ X axis	0	0	0
+ Y axis	0	0	0

Output :

Roll (RX)	Pitch (RY)	Yaw (RZ)
0	0	0

Back

Teach

Tool Orientation Set

Get

Name	Description
ID	Select the Tool Frame ID.
Input	Displays the position data of the Origin, +X axis, and +Y axis.
Output	Displays the new Tool Frame directions after calculation.
Teach	Save the current position of the robot in the table.
Tool Orientation Set	Calculate the Roll (RX), Pitch (RY), and Yaw (RZ), and then write the data to the selected Tool Frame ID.
Get	Displays the Tool frame directions which have been set for the selected Tool Frame ID.