

8. You can check the type (Rectangle / Cylinder), status (Enable / Disable), and area (Working Area / Restricted Area) settings of each workspace in the **WorkSpace** subpage.

	Type	Area
▶ 1	Rectangle(Enable)	Restricted Area
2	None	None
3	None	None
4	None	None
5	None	None
6	None	None
7	None	None
8	None	None
9	None	None

9. The **Work Space is Closed** button in the upper-right corner of the **Work Space** tab indicates that all workspace is disabled. Click the button, and it switches to **Work Space is Opened**, indicating that all workspace is enabled. Under this setting, an alarm will be triggered when you move the robot to this restricted area.

Work Space

ID1

TypeRectangle

StatusEnable

Show Alarm☒

AreaRestricted Area

Restricted Area DO

Disable

DO1

ON

Work Space is Closed

Work Space is Opened

Rectangle

	X (mm)	Y (mm)	Z (mm)
PO	467	-85	-12
PX	475	-85	-12
▶ PY	467	-20	-60

PO

PY

PX

Reset

Get

Set