

7. You can check the type (Rectangle / Cylinder), status (Enable / Disable), and area (Working Area / Restricted Area) settings of each workspace in the **WorkSpace** subpage.

	Type	Area
▶ 1	Cylinder(Enable)	Working Area
2	None	None
3	None	None
4	None	None
5	None	None
6	None	None
7	None	None
8	None	None
9	None	None

8. The **Work Space is Closed** button in the upper-right corner of the **Work Space** tab indicates that all workspace is disabled. Click the button, and it switches to **Work Space is Opened**, indicating that all workspace is enabled. Under this setting, an alarm will be triggered when you move the robot out of this working area.

Work Space

ID1

TypeCylinder

StatusEnable

☒ Show Alarm

AreaWorking Area

Restricted Area DOEnable

DO1

ON

Work Space is Closed

Work Space is Opened

Cylinder

	X (mm)	Y (mm)	Z (mm)	Radius (mm)	Height (mm)
▶ Center	340	40	-20	100	100

R

(X,Y,Z)

H

Reset

Get

Set