


6.1.2 System DO

The System DOs allow you to obtain the current status information of the robot. The System DO8 is reserved and cannot be used at present.



■ Alarm Status

Use the System DO1 to output the current alarm status or warning status. The following indicates that there are no alarms or warnings.



When an alarm or warning is triggered, the status is shown as follows. After the alarm or warning is cleared, you can reset the status with System DI8.

