

## ■ Project Execution Status

System DO5 and DO6 are both On when the project is in the RUN status.



System DO5 is On and System DO6 is Off when the project is in the STOP status.



System DO5 is Off and System DO6 is On when the project is in the PAUSE status.



## ■ Controller Ready Status

When the System DO7 is On, it indicates that the controller is ready, and the robot is now operable.

