

Return to **User IO** and the fields for DI/O names are now editable with a white background. Then, you can name the DI/O signals^{*1 *2}.

6

The screenshot shows two panels: 'User DI' on the left and 'User DO' on the right. Each panel contains a list of 19 numbered input fields (1-19 for DI, 1-12 for DO). The fields are currently empty and have a white background, indicating they are editable.

After naming, click **User IO Save** to write the settings to the project.

This screenshot shows the same 'User IO' configuration interface after the signals have been named. In the 'User DI' panel, the first two fields are labeled 'DMV_Ready' and 'visual signal_01'. In the 'User DO' panel, the first two fields are labeled 'DMV_Trigger' and 'visual trigger_01'. Above the panels, a 'User IO Save' button, represented by a floppy disk icon, is highlighted with a red rectangle.

Note:

- *1. The user-defined DI/O names are only displayed in the DRASudio; it is recommended that you select plain and straightforward names.
- *2. It is suggested that you use English letters and numbers for naming the DI/Os. Garbled text may be displayed if you use the language that is not supported by the operating system.