

6

The system automatically jumps to the **Remote IO** screen in the  **I/O** page.

Green circle  indicates that the DI/O is On; orange circle  indicates that the DI/O is Off.

You can click  or  directly, or use the RL instruction *ExtDO(@,#,ON)* or *ExtDO(@,#,OFF)**Note to switch On or Off the DIs / DOs.

Note: # indicates the DO number. @ indicates the number of the external device; in the following example,

ASD_DMC_RM32MN (1) means it is the device numbered as 1.

