

8.2.4 Calculating the inertia

After setting the Mass, Distance, and Inertia parameters, click **Calculate** to obtain the inertia at the end of J4 (effective inertia), or J5 and J6 for checking if the values exceed the robot's specifications.

Inertia calculation for SCARA

Payload

Model :

DRS60L6SS1

Get

Set

Mass :

4

 kg

CoGx

CoGy

CoGz

Distance :

0

0

0.092

 m

Inertia :

0.017

 kg*m^2

Effective Inertia :

0.050856

 kg*m^2

Calculate

Inertia calculation for VA

Payload

Model :

DRV70L7A631

Get

Set

Mass :

4

 kg

CoGx

CoGy

CoGz

Distance :

0

0

0.092

 m

ixx

iyy

izz

Inertia :

0.019

0.025

0.017

 kg*m^2

ixy

ixz

iyz

0

0

0

 kg*m^2

J5 Inertia :

0.079106

 kg*m^2

J6 Inertia :

0.017000

 kg*m^2

Calculate

If the calculation result(s) exceeds the robot's specifications, the field(s) is highlighted red as an alert.

Inertia calculation for SCARA

Effective Inertia :

0.203856

 kg*m^2

Calculate

Inertia calculation for VA

J5 Inertia :

0.079106

 kg*m^2

J6 Inertia :

0.170000

 kg*m^2

Calculate