

8.4.2 How to use the Gravity function

■ Set Gravity

- 1. Click  (Servo control) in the Quick access toolbar to switch all the motors to the Servo Off state.
- 2. Enter the end effector weight, and the X-, Y-, and Z-axis distances from the tool's center of gravity to the end of the robotic arm.
- 3. Click **SET**.

Set Gravity

☒ Enabled

☒ Normal ☐ Ceiling

Mass(kg) :

X(mm) :

Y(mm) :

Z(mm) :

SET

- 4. Go to the **Status** subpage, click **Update**, and you can find that “Gravity Compensation Deformation” is ON.

Status

Update

Status	Content
ON	Gravity Compensation Deformation
ON	Gravity Compensation Torque
OFF	Thermal Compensation
OFF	FigureAngle Compensation(SCARA)
OFF	System Reservation
OFF	System Reservation
OFF	System Reservation
OFF	FigureLength Compensation(SCARA)
OFF	Collision Detect

■ Get Gravity

- 1. Click **GET**.

Get Gravity

Mode : Normal

Mass(kg) : 5

X(mm) : 12

Y(mm) : 6

Z(mm) : 22

GET

- 2. Check the Gravity parameters read by the system.