

9.2 Temperature

Set the temperature protection level and the upper limit of the normal temperature of the motor in the **Temperature** tab.

Temperature

Level

Default: Warning will NOT decrease motion speed; Alarm will STOP current project.

Set

Setting

85 °C(40~100)

Set

Normal

Warning

Alarm

Temperature

0~85°C

86~95°C

96°C~

Joint1

0°C

Joint2

0°C

Joint3

0°C

Joint4

0°C

Name	Description
Level	Set the temperature protection level of the motor. ■ Default: Warning temp - motor does not decelerate; Alarm temp - motor stops. ■ Level 1: Warning temp - motor decelerates; Alarm temp - motor pauses until cools down. ■ Level 2: Warning temp - motor decelerates; Alarm temp - motor stops. ■ Level 3: Warning temp - motor stops.
Setting	Set the upper limit of the normal temperature of the motor. The system automatically sets the upper limit of the warning temperature by adding an increment of 10°C (50°F) to the upper limit of the normal temperature.