

9.4 Alarm History

The **Alarm History** tab records the most recent 1,024 error messages and their details; you can save the alarm history to the PC.

Alarm History					
Update		Save as			
Date	Time	Type	No.	Error Code	Description
2023-08-11	15:50:03	Axis	Joint-5	AL802	Give motion command when the alarm occurs
2023-08-11	15:50:03	Axis	Joint-4	AL802	Give motion command when the alarm occurs
2023-08-11	15:50:03	Axis	Joint-3	AL802	Give motion command when the alarm occurs
2023-08-11	15:50:03	Axis	Joint-2	AL802	Give motion command when the alarm occurs
2023-08-11	15:50:03	Axis	Joint-1	AL813	Axis error during interpretation of motion command
2023-08-11	15:50:03	Group	1	E1.823	Target position of the Line command given exceeds working range
2023-08-11	15:49:16	Axis	Joint-5	AL802	Give motion command when the alarm occurs
2023-08-11	15:49:16	Axis	Joint-4	AL802	Give motion command when the alarm occurs
2023-08-11	15:49:16	Axis	Joint-3	AL802	Give motion command when the alarm occurs
2023-08-11	15:49:16	Axis	Joint-2	AL802	Give motion command when the alarm occurs
2023-08-11	15:49:15	Axis	Joint-1	AL813	Axis error during interpretation of motion command
2023-08-11	15:49:15	Group	1	E1.823	Target position of the Line command given exceeds working range
2023-08-11	15:48:30	Axis	Joint-5	AL802	Give motion command when the alarm occurs
2023-08-11	15:48:30	Axis	Joint-4	AL802	Give motion command when the alarm occurs
2023-08-11	15:48:30	Axis	Joint-3	AL802	Give motion command when the alarm occurs
2023-08-11	15:48:30	Axis	Joint-2	AL802	Give motion command when the alarm occurs
2023-08-11	15:48:30	Axis	Joint-1	AL813	Axis error during interpretation of motion command
2023-08-11	15:48:30	Group	1	E1.823	Target position of the Line command given exceeds working range
2023-08-11	15:13:17	Warning	1	WA004	RL Stop error
2023-08-11	15:10:54	Warning	1	WA004	RL Stop error
2023-08-11	14:05:15	Warning	1	WA004	RL Stop error
2023-08-11	09:48:21	Warning	1	WA004	RL Stop error
2023-08-11	09:47:18	Warning	1	WA004	RL Stop error
2023-08-10	17:31:22	Axis	Joint-5	AL802	Give motion command when the alarm occurs
2023-08-10	17:31:22	Axis	Joint-4	AL802	Give motion command when the alarm occurs
2023-08-10	17:31:22	Axis	Joint-3	AL802	Give motion command when the alarm occurs
2023-08-10	17:31:22	Axis	Joint-2	AL802	Give motion command when the alarm occurs
2023-08-10	17:31:22	Axis	Joint-1	AL802	Give motion command when the alarm occurs
2023-08-10	17:31:21	Group	1	E1.80B	Motion command cannot be distinguished

Function	Description
Update	Update the alarm history of the controller. Up to 1,024 entries can be displayed.
Save as	Save the displayed alarm history to the PC.

9.5 About

The **About** tab displays the model numbers and information of the robot peripheral devices.

About			
1. RobotType:	DRS40L3SS1	9. TPTYPEHMI:	Not Set
2. RobotSN:	T14530002	10. TPSNHMI:	Not Set
3. ControllerType:	DCS1A00-AA	11. AxisNum:	4
4. ControllerSN:	T14530002	12. AppType:	Not Set
5. ControllerTypeM:	MS0721F	13. AppSN:	Not Set
6. ControllerSNIMS:	T14290064	14. SoftwareKeyTy:	Not Set
7. TPTYPE:	Not Set	15. SoftwareKeySN:	Not Set
8. TPSN:	Not Set	16. Decelerator:	0