

9.6.1 User Log instructions

■ **print(string or number)**

Specify the data to be retrieved. Each row in the User Log display can record a maximum of 128 characters (including symbols and spaces); the exceeded characters are truncated.

In the **RL User Log** tab, you can save the retrieved data to the PC.

Example:

print("ABC")	-- Print the string <i>ABC</i> .
print(123)	-- Print the number <i>123</i> .
print("A,B,C")	-- Print the string <i>A,B,C</i> .

■ **SetUserLogSize(string or number)**

Set the maximum size (range: 5 KB - 512 KB; default: 512 KB) of the User Log file to be saved to the USB drive.

Example:

SetUserLogSize("5")	-- Set the maximum size of the User Log file to 5 KB.
---------------------	---

■ **SetUserLogToUSB(string)**

Generate and save a User Log file (.txt or .CSV) to the USB drive connected to the controller.

Example:

SetUserLogToUSB("UserLog.txt")	-- Generate a User Log file "UserLog.txt" and save it to the USB drive.
--------------------------------	---