

1.3.4 Servo control

Click  (Servo control) to quickly set the servo to On or Off. You can operate the robot only when the servo is On.

Icon	Description
	Servo Off. Click to enable the servo.
	Servo On. Click to disable the servo.

1.3.5 TP status

There are dedicated teach pendants (TP) for different series of Delta robots. The  (TP status) icon shows whether the robot is controlled by the TP.

In DRASstudio, you can only check the TP status. Granting or taking the control is only available on the TP. When the TP is in control of the robot operation, you cannot operate the robot (such as jogging or project execution) through DRASstudio.

Icon	Description
	The robot is operable through DRASstudio.
	The robot is operable with TP.