

The **System** page in the menu provides the settings of the robot system, including **EtherNet IP**, **RS232/485**, **Language**, **Backup**, **Recovery**, and **Options**.

## 10

The screenshot shows the DRASstudio interface. On the left is a vertical menu with a 'Menu' header and a 'System' option at the bottom, represented by a gear icon. The main area displays the 'EtherNet IP' settings tab, which is highlighted with a red border. The tab title is 'Set Controller EtherNet'. Below the title, there are three rows of input fields for IP configuration:
 

- IP :** Four fields containing the values 192, 168, 1, and 1.
- SubNet Mask :** Four fields containing the values 255, 255, 255, and 0.
- Default Gateway :** Four fields containing the values 255, 255, 255, and 255. The last field is currently selected with a blue border.

 To the right of these fields is a large orange button labeled 'Set'.

## 10.1 EtherNet IP

This tab is for setting the Ethernet IP address, SubNet Mask, and Default Gateway of the robot controller. Enter the parameters in the fields and then click **Set** to complete the setting.

This image provides a detailed view of the 'Set Controller EtherNet' form. At the top left, the text 'EtherNet IP' is followed by five empty rectangular boxes. The form itself has a title 'Set Controller EtherNet' in blue. It contains three sections:
 

- IP :** Four input fields with the values 192, 168, 1, and 1.
- SubNet Mask :** Four input fields with the values 255, 255, 255, and 0.
- Default Gateway :** Four input fields with the values 255, 255, 255, and 255. The last field is highlighted with a blue border.

 A large orange button labeled 'Set' is positioned to the right of the input fields.