

10

10.5 Recovery

The Recovery function is available only when you have backed up data with the Complete Backup function in the **Backup** tab.

1. Select the backup file from the **Backup Name** drop-down list box, select the check box(es) of the item(s) to be restored in the table, and then click **Recovery**.
2. When the specified item(s) in the backup file is successfully restored to the robot controller, the Status column of the table shows “Done”.

Recovery

[Recovery from Backup to Controller](#)

Backup Name : test_20230831142747

Folder Path : C:\Delta Industrial Automation\DELTA_IA-Robot_DRASudio-V1-00-C Browse

Notes :

Version : DRASudio : DRASudio_Release_V1.00.07.55 / Firmware : 7402_12 / Library : 3000_

Content :

Check	Item	Status
☒	Global Point	Done
☐	User Frame Parameter	None
☒	Tool Frame Parameter	Done
☐	Workspace Parameter	None
☐	Controller Projects	None

Status : Done (2 / 2) Recovery

Important: make sure the robot connection is stable during recovery, or the recovery may fail.