

1.3.6 Operation mode

The robot operation mode includes T1, T2, and Auto ^{*Note}. DRAStudio only shows the operation mode. Switch between modes with the System DI4 and DI5. For detailed information, refer to Delta SCARA Robot Controller User Manual and Delta Articulated Robot Controller User Manual.

Note: robots controlled by the CE-certified controllers only support T1 and Auto modes.

Icon	Mode	JOG operation	Project execution	Max. speed
	Test mode 1	TP: operable DRAStudio: operable	Executable only in the editing mode	TCP linear speed: < 225 mm/sec
	Test mode 2	TP: operable DRAStudio: operable	Executable only in the editing mode	100%
	Auto mode	TP: not operable DRAStudio: operable	Executable with system IO	100%

T1 (Test mode 1)

For point teaching. In this mode, you can only operate the robot at low speed.

■ Jog speed

The TCP (Tool Center Point) linear speed is limited under 225 mm/sec.

■ Moving speed during project execution

When the set moving speed in the project is above 225 mm/sec, the speed is limited at 225 mm/sec.

For example, when the moving speed is set to 500 mm/sec in the program, the actual moving speed is 225 mm/sec.

■ Functional pause (System DI2)

In T1 mode, whether the System DI2 is On or Off does not trigger the functional pause.