

You can operate each external axis in the **ExternalAxis** subpage.

13

ExternalAxis

J1 PUU:

95

J2 PUU:

-24

Speed Low

Distance Short

J1P

J1N

J2P

J2N

Function	Name	Description
Current PUU display	J# PUU	Displays the current position of the external axis J# (# indicates the axis number) in units of PUU.
Quick actions*Note	Speed Low / Speed Medium / Speed High	Click to switch between the levels of moving speed.
	Distance Short / Distance Medium / Distance Long	Click to switch between the levels of moving distance.
	J#P	Click to move the external axis J# (# indicates the axis number) continuously in the positive direction at the specified levels of speed and distance.
	J#N	Click to move the external axis J# (# indicates the axis number) continuously in the negative direction at the specified levels of speed and distance.

Note: you need to click **Scan** in the **External** page before operating in the **External** page or the **ExternalAxis** subpage.

1.
- When teaching the external axis, go to the **Point** page and open the **Local** tab or **Global** tab. The following take the **Global** tab as an example.

Menu

Global

	Check	Name	X (mm)	Y (mm)	Z (mm)	RZ (deg.)	Hand	UserID	ToolID	Coordinate	Co ^
1	☒	GL_1	527.000	-112.000	775.000	6.600	1	1	2	1	
2	☐	GL_2	150.000	0.000	0.000	0.000	1	1	1	1	
3	☐	GL_3	215.000	-74.000	-42.000	158.000	0	0	0	0	
4	☐	GL_4	211.000	-97.000	-42.000	158.000	0	0	0	0	
5	☐	GL_5	400.000	0.000	0.000	0.000	0	0	0	1	
6	☐	GL_6	0.000	0.000	-50.499	0.000	0	1	1	1	
7	☐	GL_7	555.000	25.000	-50.499	0.000	0	1	1	1	
8	☐	GL_8	333.000	29.699	-50.499	108.360	0	1	1	1	

Point