

A.2.2 SafetyStatus (Read the status of functional pause)

This instruction is for reading the trigger status of the functional pause and can be used after SafetyMode(3) (disable the functional pause).

(1) Syntax

SafetyStatus(Status)

■ Status

When the status of the functional pause is read, the return value can be one of the following.

0: functional pause not triggered. The robot is in normal operation.

2: functional pause triggered when the program is not running. The motor is in the Servo Off state.

3: functional pause triggered when the program is running.

(2) Example:

```
SafetyMode(3)                --Disable the functional pause
DELAY(5)
if SafetyStatus()==0 then     --Check if the status of functional pause is 0
    print("normal operation")  --If so, print the status in the Output panel
elseif SafetyStatus()==2 then --Check if the status of functional pause is 2
    print("functional pause triggered when the program is not running")
                                --If so, print the status in the Output panel
elseif SafetyStatus()==3 then --Check if the status of functional pause is 3
    print("functional pause triggered when the program is running")
                                --If so, print the status in the Output panel
end
```

A