

1.5.1 Output

In the **Output** tab, you can check for the robot controller information read through DRASudio.

1



1.5.2 Alarm

In the **Alarm** tab, you can check for the current alarm or warning messages and the troubleshooting methods.

