

1.5.7 Function

In the **Function** tab, you can use the Modbus reading / writing function. Select the check box for the specified item, enter the specified address, select the Word size (W or DW), and then click **Write** to write the value to the controller or click **Read** to read the value from the controller.



There are three subtabs within the **Function** tab:

Subtab	Address	Description
Modbus Read Only	0x0000 - 0x0FFF	Internal memory parameters. The parameter values in this tab are read-only and write-protected.
Modbus R/W	0x1000 - 0x1FFF	Volatile parameters. You can read and write values in this tab. Data in the memory addresses is cleared to 0 after power off.
Device Latch	0x3000 - 0x3FFF	Non-volatile parameters. You can read and write values in this tab. Data in the memory addresses is retained after power off.

When you select W for the Word size, one value takes one address, such as 0x0000, 0x0001, 0x0002 and so on. When you select DW for the Word size, one values takes two addresses, such as 0x0000, 0x0002, 0x0004 and so on.

Word size	Range
W	-32,767 to +32,767
DW	-2,147,483,648 to +2,147,483,647